MP-1830

04/2026

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Warning: This product has a lithium polymer battery built-in.
3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degrees Celsius. Under and over this temperature might affect the function.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
7. The unit is not waterproof. If water or foreign objects enter the unit, stop using it immediately. If water or liquid or a foreign object enters the unit, stop use immediately.
8. Only charge with the supplied USB cable.
9. Using accessories other than the ones delivered with the product can cause abnormal functionality.

Button function distribution

Power On/Off

Use the ON/OFF switch to turn the device on or off.

The media player will automatically shut down when the system idle time reaches the user set shutdown time.

The OFF function is disabled when the player is connected to a PC or is charging.

Low battery

When the battery is low, the media player will prompt you with a low power notification. After a short period of time, it will automatically shut down. Please charge the player. Please charge the battery in time and do not turn the player on while it is charging.

MicroSD card

There is a memory card slot on the lower right side of the machine, where you can insert a MicroSD.

Connect PC

When the PC and the player are connected by a USB cable while in the power on or power off state, the PC will prompt the removable disk appears in windows. You can then copy files between the player and PC.

Main menu

After starting up, enter the main interface of the system, which is shown in the figure below:

Music

Select the Music App, press ▶‖to enter the main menu selection interface.

Press ⏮ and ⏭ to move up or down. Press ▶‖ to select the current option.

The menu options include: All songs, Artist, Album, Genre, Playlist, Create playlist.

All songs: Shows all shuffles and all songs in memory.
Artist: Arrange all the artists' songs in memory by initials.
Album: Display in alphabetical order according to the album name.
Genre: Display according to the built-in style of downloaded songs.
Playlist: Select either local or card play.
Create playlist: Add songs to the selected playlist.

Music playing interface

Press ▶‖to play or stop, press⏮ or ⏭ to go to previous or next.

Long press ⏮ or ⏭to fast forward or fast reverse the song.

Press the volume up and volume down buttons to enter the volume interface. Short or long press to adjust the volume.

Volume range:0 - 31.

Briefly Press ☰ the menu button to enter the sub-menu interface.

Music sub-menu options

When music is playing or paused, briefly press ☰ button to enter the submenu.

The menu options include play mode, sound settings, adding or deleting from playlist, timed shutdown and deleting.

Press ⏮ and ⏭ to select the browse menu, press ▶‖ to confirm option, press ↩ to return to the previous interface.

While playing, if no operation is performed under the playback interface for 5 seconds, the system will automatically switch to the music playing or paused interface.

When the playback is paused, it will not return to the pause playback interface until it shuts down automatically for 1 minute.

Video

After entering, you will see a file list interface. Use ⏮ and ⏭ browse files up and down, and press ▶‖ select a file to enter the video playback interface. It supports resume playback.

Video menu options

While playing or paused, pressing ☰ button briefly will open the menu options.

If a video is playing, it will pause in the background. The menu options include brightness, repeat, delete video, and creating playlist.

The MP3 player is compatible with AMV files and AVI files that have been converted.

Photo

Enter the image list, as shown below:

On the picture list screen, press ▶‖ to view the selected image. Press ▶‖ again to play automatically or manually. Press ⏮ or ⏭ to view images in either direction.

Briefly press ☰ button to access the menu options. Press ↩ to exit.

Sub-menu items: Brightness, Backlight Timer, Slideshow Settings, Delete Image, Create Playlist.

E-Book

In the main menu interface, select E-book and press ▶‖ to enter the E book file list.

Press ▶‖ to confirm opening the text file, which displays the current and total pages of the file. Press ⏮ or ⏭ to turn pages. Press ▶‖ to turn the page automatically or manually.

Briefly press ☰ button to enter the sub-menu options, press ↩ to exit the menu.

In the list interface, press ☰ button to access the sub-menu, which include auto play time setting, deleting ebook, bookmark selection, delete bookmark, add bookmark, font selection, background selection, and page number selection.

Recording



Press ▶‖ to start/stop/re-recording. Press ↩ exit the recording interface, choose YES/NO to save or not save the recorded file and return to the menu options interface.

When a low power signal appears in the pause mode, the system will automatically save the recording file and return to the recording interface. When the disk is full, the system will prompt that says "disk space is full!"

Recording menu options: Start recording, Recording library, Recording format, and Recording settings.

Folder

Displays all directories and files on the memory or card.

Select a file in the file list, briefly press ☰ button to display "Delete", press ↩ to cancel deletion, and press ▶‖to confirm deletion.

Tool

Enter the tool interface, as shown below:

1. Alarm Clock: Entering the alarm clock interface that displays 'Alarm volume, Alarm music, Alarm cycle, Alarm time, and Alarm (on/off)'.
2. Calendar: Press the ☰ button to switch between year, month, and day options, and press ⏮ or ⏭ to adjust the year, month, and day.

The interface is shown as follows:

3. Stopwatch: Press ▶‖ start to begin timing. The maximum time is 99 hours, 59 minutes, 99 seconds, 99 milliseconds. Press again to pause the timer. Press ⏮ to time count, up to 5 counts are supported, press ↩ to exit the stopwatch.

Setting

Enter the setting screen as follows:

1. Power Off timer: Set time range 1min~99min.
2. Display settings: Adjust brightness and backlight timer.
3. Date and time: Adjust date and time.
4. Slideshow settings: display "Time per slide. Repeat. Shuffle".
5. Language: Supports 12 languages.

6. Speaker switch: Allows you to turn the speaker on and off.
7. Information display: Player info, Disk space, Supported File Types'.
8. Format device. Format the machine or card.
9. Factory settings: Restore factory Settings.

Bluetooth

Enter the Bluetooth screen as follows.

1. Bluetooth On/Off Control: enable Bluetooth or disable Bluetooth.
2. Searching for Devices: search for devices when Bluetooth is enabled.
3. Device List: after the device search is complete, the Bluetooth device is displayed and you can select device connection. after the connection is successful, you can log out of Bluetooth. enter music, video, radio, and use Bluetooth device to play.
4. Playing Music on Bluetooth: enter music playing after connection is successful.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED. COPYRIGHT DENVER A/S

denver
denver.eu

Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, shown above. This symbol tells that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the correct recycling system. It is your duty to ensure that used batteries that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type MP-1830 is in compliance with Directive 2014/53/EU. The full text of the RED compliance statement can be found at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: MP-1830. Now enter product page, and RED directive is found under documents/other downloads.

Information on standby/off mode power consumption and power management according to the European Commission regulation (EU) 2023/826 can be found at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: MP-1830 and enter the page.

Operating Frequency Range: 2402-2480MHz
Max Output Power: 0.25W

DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics
Hotline/GSM
+45 33 29 19 00
Mandag-fredag
09:00-15:00

Fax
+45 88 33 29 19

E-mail
support.dk@denver.eu

Hotline/GSM
+46 (0)771 41 41 61

E-mail
support.se@denver.eu

Måndag - Fredag 09:00 - 16:00

Benelux
DENVER BENELUX B.V.
Stadsbroek 1-3, 6921 RE
Duiven, Netherlands

Phone **0031 (0)313 850 222**
E-mail **support.nl@denver.eu**

Spain/Portugal
DENVER ESPAÑA, S.L.U.
Calle Ribera del Loira, nº 52, 1ª Planta
Edificio Prisma
28042 Madrid
España

Italy
Phone **+39 800 164 882**
E-mail **assistenza.it@denver.eu**

Portugal
Phone **+351 308 781 110**
E-mail **assistencia.pt@denver.eu**

Germany
Denver Germany GmbH Service
Center Nord
Robert-Bosch-Straße 3
25462 Rellingen

Phone **+49 (0) 370 541 42**

E-mail
support.de@denver.eu

Montag - Donnerstag 08:00 - 16:00
Freitag 08:00 - 14:00

Austria
Denver Austria GmbH
Top 3.01, Stg 3
Wienerbergstraße 11
1100 Wien

Phone **+43 1 904 4000**
E-mail **denver@schwertner.at**

Poland
Lumarel Import Poland sp. z o.o.
ul. Kwidzyńska 6
51-416 Wrocław

Phone **+48 71 32 76 450**
E-mail **denver.serwis@lumarelimport.pl**

Godziny pracy: Pn-Pt (z wyłączeniem świąt)
8:00 - 16:00

If your country is not listed above, please contact us by e-mail: contact.hq@denver.eu

denver
DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.denver.eu

FSC