


Sound Bar User Manual

DENVER DSB-4030



EN

DA

DE

ES

FI

FR

IT

NL

NO

PL

PT

SE



FR

Cet appareil, ses
cordons et ses
accessoires sont
recyclables

À DÉPOSER
EN MAGASIN



OU

À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Soundbar User Manual

DENVER DSB-4030

Safety information


Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

- 1.This product is not a toy. Keep it out of reach of children.
- 2.Keep product out of the reach of children and pets to avoid chewing and swallowing.
- 3.Product operating and storage temperature is from 0 degree Celsius to 40 degrees Celsius. Under and over this temperature might affect the function.
- 4.Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
- 5.Do not expose to heat, water, moisture, direct sunlight!
- 6.Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
- 7.Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
- 8.Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
- 9.The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
- 10.Only charge with supplied Adaptor. The direct plug-in adapter is used as disconnect device, the disconnect device shall remain readily operable. So, make sure there is space around the power outlet for easy access.
- 11.Do not use non original accessories together with the product as this can make the product functionality abnormal.

Importance Notice for soundbar mounting on the wall:



- 1) Wall-mounted installation must be carried out by qualified personnel only. Incorrect assembly can result in severe personal injury and property damage! (If you intend to install this product yourself, you must check for installations such as electrical wiring and plumbing, which may be hidden inside or behind the wall.)
- 2) It is the installer's responsibility to verify and confirm that the wall will safely support the total load of the unit and wall brackets.
- 3) Additional tools and proposed D7.5 * L25mm screws (not included) are required for the installation.
- 4) Do not overtighten screws.
- 5) Use an electronic stud finder to check the wall type before drilling and mounting
- 6) The proposed height on the wall is 1.0~1.5meters
- 7) The strain relief (<23mm) of HDMI cable is recommended for more space during mounting.

What's in the Box?




1. Is an HDMI input jack on your TV labeled “ARC”?

If you want to use HDMI to get sound out of your TV, you have to make sure your TV supports **HDMI ARC**. On most TV's this is a specific HDMI port + you have to activate it in the TV's settings menu.




2. Connecting Your Sound Bar to Your TV or other sources:

Illustration of the Soundbar connectors for different connections:



EN	EN
HDMI-ARC	HDMI-ARC
OPTICAL	OPTICAL
LINE IN	LINE IN
DC IN	DC IN




3. Connect the Power Supplies to Sound Bar then power Insert Power Supplies to an AC outlet.

4. Hold the Power button (⏻) on the top side of the sound bar or Press RED key on the remote control to turn it on. Selecting Mode (Source) as the following instruction to enjoy your powerful sound. When the Soundbar is switched to standby, the red dot is turned on


NOTES:

- If no sound comes out through the soundbar, please check that your TV audio output is to set correct (PCM) and that HDMI is chosen as audio source.(ARC)
Please check your TV's user manual to find out how to do that.
- It will be standby within 10 minutes if no signal from Line In, BT, USB and ARC inputs. It also will be standby if the low sound from Line In need to be heard within about 15cm distance.
- RESET: Hang up is solved by disconnecting and reconnected the power supplies.
- Please use HDMI ARC for connection if your TV has this. Otherwise you can use headphone output from your TV, to the soundbar's AUX input.

The control panel on the Soundbar:



Remote control buttons:



Technical Specifications

Power consumption:	40W RMS (Amplifier Output Reference: 2x200W max)
Bluetooth version:	5.1
Bluetooth name:	DSB-4030
Soundbar measurement (approx.):	80cm x 9cm x 6.5cm (W/H/D)

Power Supplies Information:

Manufacturer:	SHENZHEN FIT-POWER TECHNOLOGY CO., LTD.
Commercial registration number:	91440300577672653M
Address:	201, NO.7 RIFU ROAD, EAST DISTRICT, BAISHIXIA COMMUNITY, FUYONG, BAOAN SHENZHEN
Trade mark	FIT-POWER
Model:	TP04-180200E
Input voltage:	100-240V~
Input AC frequency:	50/60Hz
Output voltage:	DC18V
Output current:	2.0A
Output power	36W
Max output power:	54W
Average active efficiency:	87%
Efficiency at low load (10%):	82%
No-load power consumption:	0.1W or less

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type DSB-4030 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.denver.eu and then click the search ICON on topline of website. Write model number: DSB-4030. Now enter product page, and red directive is found under downloads/other downloads.

Operating Frequency Range: 2402-2480Mhz

Max Output Power: 400W(Amplifier Output Reference,45W RMS)

DENVER A/S

Omega 5A, Soeflen

DK-8382 Hinnerup

Denmark

<https://denver.eu>

<https://facebook.com/Denver.eu>

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**
E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, n° 23 – nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain
Phone: **+34 960 046 883**
Mail: **support.es@denver.eu**

Portugal:
Phone: **+35 1255 240 294**
E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail
support.de@denver.eu

Fairfixx GmbH
Repair and service
Rudolf-Diesel-Str. 3 TOR 2
53859 Niederkassel

(for TV, E-Mobility/Hoverboards/Balanceboards,
Smartphones & Tablets)

Phone: **+49 851 379 369 69**
E-Mail: **denver@fairfixx.de**

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**
E-Mail: **denver@lurfservice.at**

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: **62 75 38 092**
E-Mail: **denver-service@letmerepair.pl**

Godziny pracy: 8 – 18 (poniedziałek – piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

