



LDB-319MK2

Denver.eu

2025



FR

Les ampoules
sont recyclables

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHÈTERIE



ou

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !


Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

- 1.This product is not a toy. Keep it out of reach of children.
- 2.Keep product out of the reach of children and pets to avoid chewing and swallowing.
- 3.Product operating and storage temperature is from 10degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- 4.Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
- 5.Do not expose to heat, water, moisture, direct sunlight!
- 6.The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or foreign object enters the unit, stop use immediately.
- 7.Only charge with supplied USB cable.
- 8.Do not use non original accessories together with the product as this can make the product functionality abnormal.
- 9.Please protect your eyes and do not look directly into the lightning prism when product is operating.
- 10.Never use old and new batteries or different types of batteries together. Remove the batteries when you are not using the system for a longer period of time. Check the polarity (+/-) of the batteries when inserting them in the product. Wrong positioning can cause an explosion. Batteries not included.

Disco light with remote control


Manual of remote controller



Note: please connect the light to the power supply and remove the battery insulator from the

remote control before use.

How to use the Disco Ball Light



1. On/off button
2. 5V USB-C input port
3. Lock Handle
4. Suction cup inside
5. Battery compartment

Option 1: Power the Disco Ball Light by using the USB charging cable with any power source (e.g., computers, power banks or power adapters).

Option 2: Power the Disco Ball Light by using 3 AA batteries (not included).

Power on the unit

Please notice that the model has 2 power options.

1. Power by USB cable only (no batteries installed).

Move the slider to ON mode and the Disco ball lights turn on.

Move to OFF to turn it off.

2. Power by batteries only (no USB cable connected)

Move slider to OFF mode and the Disco ball lights turn on.

Move to ON to turn it off.

Please notice you cannot turn the unit off if both batteries and USB cable power is installed.

Operating the suction cup



Step 1: Clean up the surface of the wall or glass.

Step 2: Remove the bottom cover.

Step 3: Pull up the lock handle.

Step 4: Press the suction up on the wall and make sure no air inside and then pull down the lock handle.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

DENVER A/S
Omega 5A,
SoftenDK-8382 Hinnerup
Denmark
www.facebook.com/denver.eu

