

65.5mm

93mm



MBP-16W
denver.eu

12/2025



Point de collecte sur www.quafairemondechute.fr
Privilégiez la réparation ou le don de votre appareil !

Safety Information page


Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

- Warning: This product includes lithium polymer batteries.
- Small parts: Keep product out of reach for toddlers under 3 years to avoid swallowing.
- Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- Never open the product. Touching the inside electric can cause electric shock. Repairs or service should only be performed by qualified personnel.
- Do not expose to heat, water, moisture, direct sunlight!
- The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
- Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
- Only charge with supplied USB cable.

ENG 1

Product overview

Power button



Reset key: When the printer is not responding, try inserting the insulated needles/toothpicks into the reset hole until the power indicator light goes off and the device shuts down. If needed, press and hold for 2 seconds to turn on the device.

How to use the product
- Power product on/off by press and hold the power button for 2 seconds.
- Press power button twice to print diagnostic page and the QR code to connect the printer with smart phone App.

ENG 2

Charging introduction

Please connect one end of the USB cable to the device and the other end to a 5V/2A adapter or computer USB port for charging.
Charge time: about 3 hours.

Indicator Light

Light steady on: Bluetooth connected.
Light flashing slowly: Bluetooth disconnected.
Green light on: Normal use status/fully charged.
Red light on: Cover open/no paper/overheat.
Yellow light on: Low battery, please charge
Yellow light flashing quickly: Charging

Note: Auto power off: The printer will automatically power off after 20 minutes without operation. You can set the timer in the App.
How to use: Usage overview

in the App.

How to use: Usage overview

- App Download
- Printer Startup
- Connected Printer
- Installation Consumables
- Edit Print

ENG 3

How to use: App Download

- Search for [AiYin] on Google Play or App Store.



- Scan the following QR code to down App.



- iOS: Turn on Bluetooth, allow AiYin App to access.
Android: Turn on Bluetooth and Location, allow AiYin App to access.
- Open AiYin App and Tap device icon in the upper left corner. Connect the thermal printer device Bluetooth name MBP-16W.
- Tap the paper type and paper width. Choose the paper type and paper width. Tap save. (If you need to customize the paper width enter the number in last row.)
- Choose the printing option.

ENG 4


Note:

- This product needs to be connected to the printer in the App.
- Due to the requirements of mobile phone system, the Android mobile phone will use the user's geographic location when connecting, so that the user needs to turn on the GPS and confirm the authorization.
- This app only supports phones with Android 7.0 or above systems.

Paper Installation Guide

1. Open cover

Lift the upper cover to open the lid



2. Put paper in

The print side is facing up



ENG 5

3. Close the cover

The end of the paper outlet needs to exceed the paper outlet of the machine



Product specifications

Printing method	Direct Thermal
Resolution	203 dpi
Battery	1200mAh, 3.7V

ENG 6

Please notice - All products are subject to change without any notice.
We take reservations for errors and omissions in the manual.
ALL RIGHTS RESERVED. COPYRIGHT DENVER A/S



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment. If the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

ENG 7

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type MBP-16W is in compliance with Directive 2014/53/EU. The full text of the RED declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on top line of website. Write model number: MBP-16W. Now enter product page, and RED directive is found under download/other downloads. Alternatively, the QR code below can be scanned and the file can be accessed directly.

Hereby, Denver A/S declares that this connected device is in compliance with Data Act Regulation (EU) 2023/2854. The Data Act (EU) 2023/2854 product data sheet is available at the following internet address: denver.eu and then click the search ICON on top line of website. Write model number: MBP-16W. Now enter product page, and the Data Act (EU) 2023/2854 product data sheet is found under download/other downloads. Alternatively, the QR code below can be scanned and the file can be accessed directly.

Information on standby/off mode power consumption and power management for products compliant with Commission Regulation (EU) 2023/826 can be found at the following internet address: denver.eu and then click the search ICON on top line of website. Write model number: MBP-16W and enter the page.



Operating Frequency Range: 2402-2480 MHz
Max Output Power: 2.26dBm

DENVER A/S
Omega SA, Søften
DK-8362 Vinnetrup
Denmark
www.denver.eu
www.facebook.com/denver.eu

ENG 8

Contact

Main contact point: contact.hq@denver.eu

HeadOffice

Denmark A/S

Omega SA, Søften

DK-8362 Vinnetrup

Denmark

Phone: +45 88 22 61 00

Print: 1700 1700 1700

E-Mail: support@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu

For all other questions, please write to:

contact.hq@denver.eu