

89.5mm

125mm



Please read carefully.



CRQ-225

Denver.eu

April 2025



ENG1

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children and pets to avoid chewing and swallowing of parts.

2. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.

3. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.

4. Warning: This product has a built-in lithium polymer battery.

5. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius.



6. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.

7. Do not expose to heat, water, moisture, direct sunlight!

8. Do not use non-original accessories together with the product as this can make the product functionality abnormal.

Note: The appearance of the speaker is for reference only, please refer to the actual product.

ENG2



ENG3

Time & Alarm Setting:

1. Press and hold the button to power on the speaker
2. To set the clock, press the button to enter hour setting mode.
3. Press the buttons to adjust the hour.
4. Press the button again to confirm the hour setting.
5. Repeat steps 2-4 to set the minutes.
6. Press the button to enter alarm setting mode.
7. Press the button to increase, or the button to decrease the alarm hour and minute.
8. Press the button to confirm the alarm time.
9. Press the buttons to select your desired alarm sound from 7 available options.
10. Press the button again to confirm the alarm settings. The alarm icon will appear on the screen.

Adjusting Alarm Volume:

The alarm volume is the same as the speaker volume. Adjust the alarm volume using the volume buttons and on the speaker.

White Noise Setting:

Press and hold the button to switch to white noise mode (a "NS" icon will appear on the screen). Use the buttons to select your preferred white noise sound from the available 7 options.

FM Radio Setting:

- Press and hold the button to switch to FM radio mode.
- Connect the provided USB Type-C charging cable to the speaker's charging port. The cable acts as an antenna. You do not need to connect the USB end of the cable to any device.
- Press the button to automatically search for and save radio stations.

TWS Stereo Function (Bluetooth Mode Only)

- If you have two CRQ-225 speakers, power on both speakers.
- Press and hold the arbitrary speaker.
- The speakers will automatically pair with each other and function as left and right channels for stereo sound

ENG4

Bluetooth Mode:

- The speaker automatically enters Bluetooth mode when powered on. A flashing Bluetooth icon will appear on the screen.
- On your phone or Bluetooth device, navigate to the Bluetooth settings menu and turn on Bluetooth
- Select " CRQ-225 " from the list of available Bluetooth devices.
- A voice prompt will confirm successful pairing. The Bluetooth connection icon will appear on the screen.

Essential parameters:

Bluetooth version: JL 5.3

Features: Bluetooth connection, white noise, clock alarm, T card, USB, AUX-IN, FM, LED ambient light

Wireless charging: 15W

Bluetooth frequency: 80HZ-20KHZ

Horn: 4 Q 5w * 2

Battery: 1200mAh

Charging time: 3-4 hours

Work time: 2-3 hours (maximum sound with light playback)

3-4 hours (70% volume)

Material: ABS fabric+PC+silicone

Input voltage rating: 9V 2A; 5V-3A

SHENZHEN PUSHIDA ELECTRONIC TECHNOLOGY CO.,LTD

Address:

4th Floor 1 Factory Building Haosan Industrial Park Heyi Community Shajing

Street Baoan Area Shenzhen, Guangdong China

Model identifier : PSD19-C

Input voltage : 100V-240V

Input AC frequency : 50Hz/60Hz

Output voltage : 5V/9V/12V

Output current : 5V3A/9V2.22A/12V1.67A

Output power : 20W

Average active efficiency : 85.54%

No-load power consumption : 0.3W

ENG5

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic

ENG6

equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type CRQ-225 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: CRQ-225. Now enter product page, and RED directive is found under downloads/other downloads.

Bluetooth frequency: 80HZ-20KHZ

FM frequency: 87.5MHz-108MHz

Max Output Power: 10W

DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.facebook.com/denver.eu

ENG7

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: +45 86 22 61 00
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Germany

Denver Germany GmbH Service
Max-Emanuel-Str. 4
94036 Passau

Phone: +49 851 379 369 40

E-Mail
support.de@denver.eu

Fairfixx GmbH
Repair and service
Rudolf-Diesel-Str. 3 TOR 2
53859 Niederkassel

(for TV, E-Mobility/Hoverboards/Balanceboards,
Smartphones & Tablets)

Phone: +49 851 379 369 69
E-Mail: denver@fairfixx.de

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: 0900-3437623
E-Mail: support.nl@denver.eu

Austria

Lurt Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: +43 1 904 3085
E-Mail: denver@lurfservice.at

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, n° 23 – nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain
Phone: +34 960 046 883
E-Mail: support.es@denver.eu

Portugal
Phone: +35 1255 240 294
E-Mail: denver.service@sattiel.com

Poland

LetMeRepair Poland sp. z o.o.
ul. Czapetochowska 140
62-800 Kalisz

Phone: 62 75 38 092
E-Mail: denver-service@letmerepair.pl

Godziny pracy: 8 – 18 (poniedziałek – piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
denver.eu
facebook.com/denver.eu

