

BTM-618

Denver.eu

01/2025



EN-1

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

- 1.This product is not a toy. Keep it out of reach of children.
- 2.Warning: This product includes lithium polymer batteries.
- 3.Keep product out of the reach of children and pets to avoid chewing and swallowing.
- 4.Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- 5.Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
- 6.Do not expose to heat, water, moisture, direct sunlight!
- 7.Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
- 8.Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.

EN-2

- 9.Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
- 10.The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
- 11.Only charge with supplied USB cable.
- 12.Do not use non original accessories together with the product as this can make the product functionality abnormal.
- 13.This product does not support harmonized charging

Scope of Supply



- Speaker x 1
- Wired Karaoke Microphone x 1
- Type-C charging cable x 1
- User manual x 1

Technical Data

- Bluetooth version: V5.3
- Rated input: 5V-1A
- Speaker: 10W*1
- Speaker Battery: 1800mAh (rechargeable)
- Frequency range: 100Hz-18 KHz
- Bluetooth working distance: Up to 10 meters

EN-3

Product Overview



EN-4

- Speaker Buttons:**
- 1.VOL-/ VOL+button
 - 2.Previous track /MIC VOL-
 - 3.Next track /MIC VOL+
 - 4.Power ON&OFF/Play&Pause
 - 5.Mode for Bluetooth, USB, TF, Aux-in
 - 6.Lighting Mode
 - 7.USB-C charging port
 - 8.USB for audio playback
 - 9.MIC 1
 - 10.MIC 2
 - 11.AUX in port
 - 12.Micro SD/TF card slot

Wired Microphone Buttons:

- 1.Power ON&OFF
- 2.Detachable wire

Powering On/Off

To turn the unit on and off, long press the ON/OFF button.

Charging the Battery

Please use the provided Type-C cable for charging. Plug the Type-C end into the Type-C port of the unit and the other end into the USB port of a PC, wall charger, or other 5 V chargers.

Playing mp3 files from microSD or USB devices

- 1.Insert the USB drive into the USB port or the Micro SD card into the TF slot.
- 2.Play, pause or skip a selected track using the

EN-5

controls on the speaker.

Bluetooth Operation

If you have used Bluetooth connection before, the system will search for the device last connected. When the device is found, the system will reconnect automatically.

Pairing a Bluetooth Device for the First Time

- 1.Turn the unit on. You'll hear an alert tone.
- 2.Turn on your external device. Refer to its user manual for instructions on pairing and connecting Bluetooth devices.
- 3.Using the controls on your Bluetooth device, select "BTM-618" in your Bluetooth settings to pair.
- 4.When successfully paired and connected, the unit will emit an alert tone. After the initial pairing, the unit will stay paired unless unpaired manually by the user.

Cautions

- 1.Do not use abrasive cleaners to clean this product.
- 2.Keep this product away from fire or heat sources, such as cooking stoves.
- 3.Do not expose this product to direct sunlight for a long time.
- 4.Do not throw this product into the fire to avoid an explosion.
- 5.Never attempt to disassemble or modify this product, as it contains no after-service components.
- 6.Do not use this product in the rain.
- 7.If you do not plan to use this product for a long

EN-6

time, please store it in a dry environment and charge the speaker at least once a month to extend its life and avoid extreme temperatures and dust. Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

EN-7

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type Denver BTM-618 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: Denver BTM-618. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range: 2.402-2.480 GHz
Max Output Power: 100W/10W RMS

DENVER A/S

Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

www.facebook.com/denver.eu

EN-8

Contact

Main contact point: contact.hq@denver.eu

Nordics
Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
Phone: +45 86 22 61 00
(Push "T" for support)
E-Mail: support.de@denver.eu

Germany
Denver Germany GmbH Service
Max-Emanuel-Str. 4
94036 Passau
Phone: +49 851 379 369 40
E-Mail: support.de@denver.eu

Benelux
DENVER BENELUX B.V.
Barvoutswaard 13C+D
3449 HE Woerden
The Netherlands
Phone: 0900-3437623
E-Mail: support.nl@denver.eu

Austria
Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien
Phone: +49 851 379 369 69
E-Mail: denver@lurf.at

Spain/Portugal
DENVER SPAIN S.A.
Ponda Augustes y Louis Lumiere, nº 23 - nave 15
Parque Tecnológico
46900 PATERNA
Valencia (Spain)
Phone: +34 960 046 883
Mail: support.es@denver.eu

Poland
LetMeRepair Poland sp. z o.o.
ul. Czapłachowska 140
62-800 Kalisz
Phone: 62 75 38 092
Mail: denver-service@letmeprepair.pl

Portugal
Phone: +35 1255 240 294
E-Mail: denver.service@sattfiel.com

Portugal
Phone: +35 1255 240 294
E-Mail: denver.service@sattfiel.com

Portugal
Phone: +35 1255 240 294
E-Mail: denver.service@sattfiel.com

If your country is not listed above, please write an email to contact.hq@denver.eu

