



BTL-330

Denver.eu

04/2025



Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

- 1.This product is not a toy. Keep it out of reach of children.
- 2.Warning: This product includes lithium polymer batteries.
- 3.Keep product out of the reach of children and pets to avoid chewing and swallowing.
- 4.Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- 5.Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
- 6.Do not expose to heat, water, moisture, direct sunlight!
- 7.Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
- 8.Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
- 9.Microwaves emitting from a Bluetooth device may affect

the operation of electronic medical devices.
10.The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.

- 11.Only charge with supplied USB cable.
- 12.Do not use non original accessories together with the product as this can make the product functionality abnormal.
- 13.This product does not support harmonized charging.


Scope of Supply

- Speaker x 1
- Type-C charging cable x 1
- User manual x 1

Technical Data

- Bluetooth version: V5.3
- Rated input: 5V-0.5A
- Speaker: 5W*2
- Speaker Battery: 1200mAh (rechargeable)
- Frequency range: 50Hz-20 KHz
- Bluetooth working distance: Up to 10 meters

Product Overview



Speaker Buttons:

1. Power ON&OFF/Lighting
2. Mode for Bluetooth, USB, TF/TWS
3. VOL+ button/Next track
4. VOL- button/Previous track
5. Play&Pause/Handsfree
6. USB-C charging port
7. USB for audio playback
8. Micro SD/TF card slot

Charging the Battery

Please use the provided Type-C cable for charging. Plug the Type-C end into the Type-C port of the unit and the other end into the USB port of a PC, wall charger, or other 5 V chargers.

Powering On/Off

To turn the unit on and off, long press the ON/OFF button.

1. Bluetooth

Turn on and enter the Bluetooth mode, select "BTL-330" in your Bluetooth settings to pair. When successfully paired and connected, the unit will emit an alert tone. After the initial pairing, the unit will stay paired unless unpaired manually by the user.

2. TF card/Micro SD

Insert the Micro SD card into the TF slot.

3. USB disk

Insert the USB drive into the USB port.

4. LED light

Short press M to turn on or turn off colorful lights.

5. TWS

In BT mode, long press M to connect or cancel TWS.

6. Handsfree

When the call comes in, short press ► to answer or long press to hang up, press ► twice to call back.

Cautions

- 1.Do not use abrasive cleaners to clean this product.
- 2.Keep this product away from fire or heat sources, such as cooking stoves.
- 3.Do not expose this product to direct sunlight for a

long time.

4.Do not throw this product into the fire to avoid an explosion.


5.Never attempt to disassemble or modify this product, as it contains no after-service components.

6.Do not use this product in the rain.

7.If you do not plan to use this product for a long time, please store it in a dry environment and charge the speaker at least once a month to extend its life and avoid extreme temperatures and dust.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type Denver BTL-330 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: Denver BTL-330. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range: 2.402-2.480 GHz
Max Output Power: 2x50W/2x5W RMS

DENVER A/S
Omega 5A, Soeflen
DK-8382 Hinnerup
Denmark
www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeflen
DK-8382 Hinnerup
Denmark

Phone: +45 86 22 61 00
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Germany

Denver Germany GmbH Service
Service Center
Max-Emanuel-Str. 4
94036 Passau

Phone: +49 851 379 369 40

E-Mail
support.de@denver.eu

Monday - Thursday 09:00 - 16:30
Friday 09:00 - 14:00

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: +43 1 904 3085
E-Mail: denver@lurfservice.at

Poland

LetMeRepair Poland sp. z o.o.

ul. Czystałowska 140
62-800 Kalisz

Phone: 62 75 38 092
E-Mail: denver-service@letmerepair.pl

Godziny pracy: 8 - 18 (poniedziałek - piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeflen
DK-8382 Hinnerup
Denmark

denver.eu
[facebook.com/denver.eu](https://www.facebook.com/denver.eu)



ENG-1

ENG-2

ENG-3

ENG-4

ENG-5

ENG-6

ENG-7