



BTL-65

Denver.eu

09/2025



EN-1

EN Instruction manual

SAFETY

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

- 1.This product is not a toy. Keep it out of reach of children.
- 2.Warning: This product includes lithium polymer batteries.
- 3.Keep product out of the reach of children and pets to avoid chewing and swallowing.
- 4.Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- 5.Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
- 6.Do not expose to heat, water, moisture, direct sunlight!
- 7.Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
- 8.Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
- 9.Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
- 10.The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
- 11.Only charge with supplied USB cable.
- 12.Do not use non original accessories together with the product as this can make the product functionality abnormal.
- 13.Please protect your eyes and do not look directly into the lightning prism when product is operating.
- 14.This product does not support harmonized charging

EN-2

BEFORE THE FIRST USE

- Please charge the battery for at least 8 hours before your first use of device.
- If the device is not used for a long period of time, the battery may be out of power. Please charge the battery.
- Connect the supplied USB-cable to the speaker and an external power source. During charging the indicator will be red.

PARTS DESCRIPTION

1. Disco light dome
2. LED-M key
3. Aux jack
4. DC jack
5. On/Off switch

USE

Bluetooth playback

- Turn on the device by using the ON/OFF switch.
- Turn on your Bluetooth device, search for the speaker and choose to pair. (If your Bluetooth device ask a password, please insert "0000".)
- Once paired successfully, both the speaker and your Bluetooth device will store the device.

Aux playback

- Connect your external device to the unit by using a standard 3,5mm line-in cable.
- The connection is made, you can start playback on your external device.

CHARGING

- Charge the battery with the supplied USB cable. You can connect the cable to a computer or USB power supply. The charging indicator LED remains on while the battery is charging.
- The device will be fully charged in about four hours.
- When the battery is running low, the device will beep.

LED function

- Press and hold the LED--M key to turn the Disco light dome on or off.
- Press the LED-M key to switch between different disco light modes.

EN-3

CLEANING AND MAINTENANCE



- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



Denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

EN-4

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type BTL-65 is in compliance with Directive 2014/53/EU. The full text of the RED declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: BTL-65. Now enter product page, and RED directive is found under downloads/other downloads.

Information on standby/off mode power consumption and power management for products compliant with Commission Regulation (EU) 2023/826 can be found at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: BTL-65 and enter the page.

Operating Frequency Range: 2.402-2.480GHZ
Max Output Power: 2x30W/2x3W RMS

DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.denver.eu
www.facebook.com/denver.eu

EN-5

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: +45 86 22 61 00
(Push "1" for support)

E-Mail

For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barvoetswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: 0900-3437623
E-Mail:support.nl@denver.eu

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, n° 23 - nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain

Phone: +34 960 046 883
Mail:support.es@denver.eu

Portugal:

Phone: +35 1255 240 294
E-Mail:denver.service@sattfiel.com

Germany

Denver Germany GmbH Service
Service Center
Max-Emanuel-Str. 4
94036 Passau

Phone: +49 851 379 369 40

E-Mail
support.de@denver.eu

Monday - Thursday 09:00 - 16:30
Friday 09:00 - 14:00

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: +43 1 904 3085
E-Mail:denver@lurfservice.at

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: 62 75 38 092
E-Mail:denver-service@letmerepair.pl

Godziny pracy: 8 - 18 (poniedziałek - piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

